


Connectivity Diagram



EC10



Floor Button Control Relays :10 Fingerprint Capacity : 3,000 Proximity Card Capacity : 30,000

Event Capacity: 1,00,000

Communication to computer: Ethernet, RS485

Communication to EX16; RS485

Number of supported EX16 boards: 3

EX16

Extension Board to Control 16 floors

Elevator Controller EC10 Controlling 10 floors elevator keypad, extension relay board EX16 can connect with the master controller to control another 16 floors.



Floor Button Control Relay : 16 Communication to EC10 : Rs485 RS485 address : Set by DIP switch

Power Supply: 12V DC 1A